



# Quick Start Guide



## 1 Make sure the voltage setting is correct



Back panel of TubeMagic D1 Plus DAC

Please check if the voltage setting on the back panel is set to the correct one. It will be either 110v or 220/240v depending on the country. Wrong voltage setting will damage the DAC.

## 2 Check what's included:



Line-in cord

x1



1/8" (3,5mm) to 1/4" (6,5mm)  
Headphone jack converter

x1



Quick Start Guide

x1




Power cord

x1



USB cable


x1



x1

## 3 Front panel controls and back panel inputs/outputs

Front panel of TubeMagic D1 Plus



Power


Volume knob

Audio source knob

Line-in  
Socket

Headphone  
Socket

Back panel of TubeMagic D1 Plus



USB  
input

Optical  
Toslink  
digital  
audio  
input

Coaxial  
S/PDIF  
digital  
audio  
input

Analog  
audio  
input

Analog  
audio  
output

Tube  
Pre-amp  
audio  
output

Power  
voltage  
switch

Power  
cord  
socket

# 4 How to connect TubeMagic D1 Plus DAC into your audio setup




AppleTV / Airport Express  
Network Media Player  
Network Audio Player  
Digital Media Adapter

Toslink(Optical) or  
S/PDIF(Coaxial) Cable




Playstation / Wii / Xbox





Toslink(Optical) or  
S/PDIF(Coaxial) Cable






Line-in Cord



iPod / Portable Audio Player



## 4 How to connect TubeMagic DAC D1 Plus into your audio setup



## 5 Need help?

Visit us at <http://www.mav-audio.com/base/support> for knowledge base or contact support via submitting a ticket.